MATERIALS AND EQUIPMENT

The following materials and equipment were used to complete the experiment:

- 1. NodeMCU ESP8266
- 2. LM35 Temperature Sensor
- 3. MicroUSB cable
- 4. Laptop
- 5. Connecting Wires
- 6. Breadboard
- 7. Arduino IDE (Software)
- 8. Internet Connection
- 9. ThingSpeak Account

PROCEDURE

The following steps were followed to complete the experiment:

- Connect NodeMCU ESP8266 with laptop using MicroUSB cable, and then install ESP8266 specific software packages using board manager in arduino software.
- 2. Go to File \rightarrow Preferences.. Then paste the link in Additional Board Manager URL's: $https://arduino.esp8266.com/stable/package_esp8266com_index.json$
- 3. Install ESP8266 software packages using the Arduino IDE's board manager.
- 4. Select NodeMCU1.0 ESP-12E module in the tools section of the Arduino IDE.
- 5. Connect LM35 sensor to NodeMCU (3V to 1st pin, A0 to 2nd pin, GND to 3rd pin).
- 6. Set up a ThingSpeak account and create a channel.
- 7. Download and install ThingSpeak libraries in the Arduino IDE.
- 8. Write Arduino program for NodeMCU ESP8266 to read LM35 data and send it to ThingSpeak.
- 9. Upload the program to NodeMCU.
- 10. Create a ThingSpeak IoT web dashboard for temperature monitoring.
- 11. Share the temperature sensor data globally through ThingSpeak.
- 12. Install device driver software if the port is not available.